


Sette™ 270

Remove the grinder, bin, power cord, and bean hopper from the box. Install lid onto bean hopper. With the shutoff knob facing the 11 o'clock position, line up the 3 hopper tabs with the slots in the top of the grinder. Set the hopper in place and rotate firmly clockwise until the hopper clicks into place. Note: Grinder motor will not turn on with the hopper removed. Ensure the shutoff knob is in the open position.



Macro/micro grind size adjustment:

The Macro adjustment moves from coarse (31) to fine (1). With the grinder running, turn the knob to the right to move from coarse to fine. Espresso: start at 9E Manual brew: start at 20E. The micro adjust is the bottom ring, from finer (A) to Coarser (I). Turn to the right to move from coarse to fine. The micro adjust is stepless with guidelines for repeatability.

Convertible device holder:

The black arms that hold the grounds bin can also be used to hold most popular brewing devices such as V60, Kalita Wave, Clever, and Able Kone. To convert the arms to hold a portafilter, push in on the right arm and swing it down and to the left. To convert the arms to hold the grounds bin or other brewing devices, push in on the right arm and rotate to the right and up. The left arm will automatically move into

position. In the center, above the arms, is a hook for holding the lip of your portafilter, providing stability. This hook can be rotated out of the way by pressing down on the hook and then rotating it left or right. To return to center position simply press down and rotate it back to center.


Adjusting the portafilter hook:

When grinding directly into a portafilter, you must first convert the arms to portafilter mode and swing the hook to the front. The hook is designed to support the top lip of your portafilter. It is imperative that your hook is adjusted so that your portafilter sits level. To adjust the hook, loosen the 2mm hex screw that sits below the hook, adjust portafilter hook up or down, and tighten screw once in the proper position.

WARNING: The Sette grinds at a very high speed, be careful not to overfill your portafilter or bin! If a mound of coffee backs up into the chute it will clog the grinder.

Time Based Grinding Operation:

Place the portafilter or the grounds bin in the grinder. Press a preset button (1,2,3). The screen will show the corresponding programmed grind time in seconds. Press Start (>||) button to begin grinding. While grinding, the screen will count UP the seconds and stop when the preset time is reached. When the screen reaches the preset time, the motor will stop and the display will reset again to the programmed time. For manual quantities of ground coffee, press and hold the START button until you obtain the desired amount of coffee, then release the START button, the grinder will then stop with the screen showing the total amount of seconds run. To get out of manual mode, press STOP.



Programming:

The Sette 270 is equipped with three programmable buttons. The buttons are simply labeled 1,2,3. These programmable buttons only adjust the amount of grind time, they do not adjust the grind setting (i.e. Coarse/Fine). Each button comes from the factory with the following presets: Time: 1=10s, 2=20s, 3=30s

You can easily program more or less grinding time as follows:

1. **Select a Preset button.**
2. **Press the up or down arrow buttons to adjust the seconds**
3. **Once you have reached the desired time setting, press and hold the desired preset button for 3 seconds. The screen will blink to confirm the setting is stored.**

To program the other buttons repeat steps 1-3.

Bag of Tools:

We have included a small bag with tools and shims.

5mm hex key used for removing the cone burr from the holder.

Shims used for recalibrating the machine to a finer range.

2mm hex key used for adjusting the portafilter hook.

Detailed instructions can be found in the full manual, see link below.

Need Help?

If you have any questions or concerns, please email: support@baratza.com

The full manual can be found on our website at: www.baratza.com/documentation/

For video instructions and troubleshooting guides: www.youtube.com/user/Baratzallc1/search?query=sette

SAFETY INFORMATION:

Please read the information below very carefully. It contains important safety information for this appliance. Please keep these instructions for future reference.

- ! Use only with AC current and the correct voltage. See the label on the base of the grinder to determine the correct voltage.
- ! Only clean the grinder housing with a dry or slightly damp cloth. Do not immerse the grinder, plug or cord in water or any other liquid.
- ! Baratza will not accept any liability for damage, injury, or warranty if the grinder is used other than for its intended purpose (i.e. grinding roasted whole coffee beans) or is improperly operated or repaired.
- ! Keep the appliance and its cord out of reach of children aged less than 8 years
- ! Do not operate the grinder with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard
- ! Do not leave your grinder unattended while turned ON.
- ! This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- ! Cleaning and user maintenance shall not be made by children without supervision.
- ! Always unplug the grinder from the electrical supply before assembling, disassembling or cleaning.
- ! To unplug, grasp plug and remove from the outlet. Never pull on the cord.

CAUTION: ALWAYS unplug the electrical supply cord prior to cleaning the grinder.